


VirtuFit Multifunctional Door Gym Deluxe


PARTS LIST

-  A: 8x Plug
-  B: 8x Screw
-  C: 10x Lock nut
-  D: 10x Screw
-  E: 2x Screw
-  F: 2x Brackets (J)
-  G: 1x Screwdriver
-  H: 1x Wrench


ASSEMBLY INSTRUCTION




ATTACHING BRACKETS(J)




Center the brackets (J) and mark the holes.



Drill the marked holes. Use a 6 mm drill bit.



Place the plugs in the drilled holes.




Place the brackets (J) in the right position and secure them.

ATTACHING DOOR GYM

Back of the door opening








Back of the door opening

Front of the door opening




Hook the pull-up bar at the back into the brackets (J).

Onderdelenlijst

-  A: 8x Plug
-  B: 8x Schroef
-  C: 10x Borgmoer
-  D: 10x Schroef
-  E: 2x Schroef
-  F: 2x Beugels (J)
-  G: 1x Schroevendraaier
-  H: 1x Moersleutel

Montage optrekstang



Beugels (J) bevestigen

- 

1 Centreer Beugels (J) en markeer de gaten.
35 cm
F
F
Deur opening
- 

2 Boor de gemarkeerde gaten voor. Gebruik een 6 mm boor.
Boor 6 mm
Muur
- 

3 Plaats de pluggen in de voorgeboorde gaten.
A
Muur
- 

4 Plaats de beugels (J) op de juiste positie en maak deze vast.
B
B
G

Optrekstang bevestigen

Achterkant deur opening

Achterkant deur opening

Voorkant deur opening

